

GS120 Wood chipper assembly details




1、Open the packing take out all parts




2、Assemble the wheels shaft




3、Assemble draw bar





4、Assemble discharge chute





One step




Two step





1) Discharge rubber plate



2) Install discharge chute




5、Assemble Infeed chute part

1) 、Install emergency stop switch



2) assemble Infeed chute



6、 Insert emergency stop switch and Limit switch connector



7、 GS120 complete the installation

